

P3 3-Blade Electric Shaver

User Manual

Model: LFESP3-P

laifen

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions are required to always be followed, including the following:

PLEASE READ ALL INSTRUCTIONS BEFORE USING. SAVE THESE INSTRUCTIONS

DANGER

To reduce the risk of electric shock:

1. If the appliance falls into water while charging, do not reach into the water for it. Unplug the appliance immediately.
2. Do not use while bathing or in the shower.
3. Except when charging, always unplug this appliance from the electrical outlet immediately after using.
4. Do not clean the appliance while it is charging.

WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

2. Use this appliance only for its intended use as described in the User Manual. Do not use attachments not recommended by the manufacturer.
3. Please check the entire appliance, charging cable, and accessories regularly for damage. If any damage is found, stop using it immediately and replace or repair it through official channels.
4. Keep the charging cable away from heated surfaces.
5. Never drop or insert any object into any opening.
6. Do not use outdoors or operate while aerosol (spray) products are being used.
7. Do not use this appliance with a damaged or broken shaver head, as it has the potential to result in facial injury.
8. This appliance must only be supplied at Safety Extra Low Voltage corresponding to its markings.
9. This appliance is waterproof and can be cleaned under an open water tap.

Warning: Unplug the charging cable before cleaning the appliance with water.




CAUTION

1. This appliance complies with the safety standards for electromagnetic devices. If you have a pacemaker or other implanted device, consult your physician or the implant manufacturer prior to use.
2. Battery terminals should be isolated from metal objects to avoid short circuits.
3. This appliance contains a non-replaceable battery. When the battery reaches the end of its lifespan, it should be properly handled by professionals according to the disassembly instructions in the User Manual and local recycling regulations.
4. If a battery leak is detected, stop using the appliance immediately. Dispose of the leaking battery in accordance with local environmental laws and guidelines. Do not discard it with regular household waste. If battery fluid leaks and accidentally contacts your eyes, do not rub your eyes. Rinse with clean water (such as tap water) and seek medical attention immediately.

5. Recommended ambient temperature for charging is 0°C – 30°C (32°F – 86°F). It may take longer to charge or the battery may fail to charge properly in extremely high or low temperatures.
6. Never use compressed air, scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.
7. Enable Travel Mode to lock the appliance when transporting it to prevent accidental activations.
8. To maintain optimal performance, we recommend you replace the shaver head once a year. If it is damaged or deformed in any way, replace it immediately.
9. It's normal for your skin to feel slightly irritated after your first few shaves. Give yourself an adjustment period of two to three weeks to adapt.
10. Do not share the appliance with others as doing so may cause an infection or inflammation.

Appliance Information




Parts and Accessories

Shaver Body^① × 1, Shaver Head^② × 1, Protective Cap^③ × 1, Charging Cable^④ × 1.

①



②



③



④



Specifications

Name: Laifen P3 3-Blade Electric Shaver • Model: LFESP3-P • Working Voltage: 3.8V⁻⁻⁻ • Charging Input: 5V⁻⁻⁻1A • Battery Capacity: 1000mAh • Charging Time: ~1.5 Hours • IP Code: IPX7

Starting Your Shaving Experience

Step 1: Enabling/Disabling Airplane Mode

This shaver features a Airplane Mode, designed to prevent accidental activations during storage or transport.

Enable: While Airplane Mode is disabled, long press the power button for 2 seconds until the Travel Mode indicator turns on.

Disable: While Airplane Mode is enabled, long press the power button until the Travel Mode indicator turns off.

Step 2: Turning the Shaver On/Off

While the shaver is off and Airplane Mode is disabled, press the power button briefly to turn it on. Press it again to turn it off.

Step 3: Start Shaving

Place the foil of the shaver at a right angle against the skin and shave against the direction your beard grows. **Do not apply excessive pressure** to avoid potential skin irritation or injury.

For the beard under the chin and around the throat, stretch the skin to lift the hairs for a better shave.





* To prevent damage to the shaver foil, do not use just a section of the shaver foil for shaving.

Charging Information

If there is water inside the charging port, be sure to dry it thoroughly before charging.

1. A third-party adapter must be purchased separately. Users must use a 5V adapter, preferably one with an IPX4 rating or higher. Avoid charging in humid environments such as bathrooms to ensure electrical safety.
2. Before first use, fully charge the shaver until the power indicator turns a steady white.
3. The shaver cannot be used while charging. Disconnect the charging cable before use.
4. When charging, please take note of the following:
 - Properly connect the USB-C side of the charging cable to the bottom of the shaver (on a USB-C charging cable, connect either side). Do not force the connection to prevent damage.
 - Plug the charging cable into a power adapter and charge using an AC 100-240V, 50-60Hz power outlet.
 - During charging, the power indicator will pulse white to indicate charging is in progress.
 - When fully charged, the power indicator will turn a steady white.
5. Use only with a USB Power Source on a certified product, such as on a computer, receptacle, lamp, class 2 power supply, or automotive adapter.

Indicator Status

Airplane Mode Indicator	When enabling Airplane Mode, turns on and off quickly and a sound is played.	
	When disabling Airplane Mode, stays lit until Travel Mode is disabled and a sound is played.	
Power Indicator	During Use	Steady White Light: Over 15% battery remaining.
		Blinking Red Light: Battery is low, please charge the shaver.
		Steady Red Light : Battery is critically low, please charge the shaver.
	While Charging	Steady White Light: Fully charged.
		Blinking White Light: Charging in progress.

Cleaning and Maintenance

To maintain optimal performance, we recommend you clean your shaver regularly.

* Before cleaning, unplug the charging cable from the shaver.



1. Before cleaning, please turn off the power.

Cleaning the Shaver Head



2. Use a small brush to remove hair from the shaver head.



Rinsing with Water



3. Remove the shaver head and rinse both the head and the drive shaft of the shaver body separately with clean water.





4. After rinsing, gently shake the shaver body a few times to remove excess water, then wipe off any remaining droplets with a dry cloth.

*When shaking the shaver, be careful not to hit the sink or other objects, as this may cause damage.



5. Let the shaver air dry in a cool place away from direct sunlight.

*Do not use any cleaning agents other than clean water, as this may cause damage.

Using Lubricating Oil

To maintain long-term shaving comfort and optimal performance, it is recommended to regularly use lubricating oil. Follow these steps:



1. Turn off the shaver.
2. Apply one drop of Lubricating Oil to every shaver foil.
3. Turn on the shaver and run it for approximately ten seconds.
4. Turn off the shaver and wipe off any excess oil with a soft cloth.

* Lubricating oil and brush are not included with this shaver.

DISPOSAL AND RECYCLING INFORMATION



Correct Disposal of This Product (Waste Electrical & Electronic Equipment) (Applicable in countries with separate collection systems) This marking on the product, accessories, or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

BATTERY DISPOSAL INFORMATION

This appliance contains Li-ion rechargeable batteries. In general, the life expectancy and battery life of these batteries vary with usage, so avoid leaving them discharged or unused for extended periods. Caution: Do not open, damage, or expose the batteries to conducting materials (metal), moisture, liquid, fire, or heat. Doing so may cause the batteries to leak or explode, resulting in personal injury. The built-in rechargeable batteries contain substances that could potentially harm the environment and may require disassembly for proper recycling, as per your country or region's laws. For professional guidance on battery removal or if the batteries cannot be removed, kindly consult Laifen directly or take the electric shaver to a government-designated recycling center.



Battery Removal Steps:

1. Ensure that the battery is completely depleted before removing it.
2. Remove all accessories from the appliance.
3. Use a tool to remove the screws from the bottom cover. Then, take out the cover with the motor and battery assembly.
4. Use a tool to remove the screws from both sides of the battery assembly. Then, separate the battery assembly from the cover and motor.
5. Use a tool to remove the screws, soldering, and terminals from the PCBA. Then, take out the PCBA motherboard and use a tool to remove the battery.

* After removing the battery, do not connect the appliance to a power source.

Troubleshooting

Issue	Potential Cause	Solution
Poor shaving performance	Hair or dirt clogging the shaver	Clean the shaver head.
	Damaged or worn-out shaver head	Replace the shaver head.
Power button not working	The shaver is charging	Unplug the charging cable before use.
	Travel Mode is enabled	Long press the power button to disable Travel Mode.
	The battery is out of power	Charge the shaver.
	Power button malfunction	Contact support for assistance (see below).
Indicator light not lighting up during charging	Poor connection between the charging cable and port	Clean the charging port.
	Damaged charging cable	Replace the charging cable.
	Indicator light or circuit malfunction	Contact support for assistance (see below).
Long charging time	Battery or circuit malfunction	Contact support for assistance (see below).
Skin irritation after shaving	Excessive pressure	Do not apply excessive pressure to avoid potential skin irritation or injury.
	Skin has not adapted yet	After using for 2 - 3 weeks, your skin will adapt to the shaver and the sensitivity will subside.
Laifen Customer Support: csteam@laifentech.com		

After-Sales Support

Return Policy

The return period may vary depending on the regulations of the region and store where the sales order is placed. Please refer to the order purchase page or relevant store information for the specific return period. If you have any questions, please contact Customer Support at csteam@laifentech.com.

To be eligible for a refund, you must:

- Return the appliance with all included accessories and gifts.
- Return them in their original packaging.
- Provide a valid proof of purchase.
- Ensure the appliance and accessories are resalable.

Return shipping costs:

- Returns caused by appliance quality issues will have shipping costs covered by Laifen. Return them in their original packaging.
- Returns for any reason other than appliance quality are the responsibility of the customer and all costs associated with returning the appliance, including shipping costs, will be handled by the customer.

Warranty & Support

Laifen 2-year limited warranty*

Laifen offers a 2-year limited warranty on the electric shavers. Within two years from the date of purchase, if your appliance fails to function properly due to material or workmanship defects, we will provide repair or replacement services. Please note that depending on the availability of stock, the replacement may come in a different color or be an equivalent model. Laifen's limited warranty does not override your statutory rights under local consumer laws. Coverage may differ based on regional legal requirements, and the limited warranty is only valid in the country or region of purchase.

What is not covered under warranty:

- Purchases from unauthorized resellers.
- Warranty period has expired.
- Appliances without a valid proof of purchase.
- Appliances that have been modified, altered, or repaired through unofficial channels.
- Appliances that were used for any purpose other than shaving.
- Appliances used for professional or commercial purposes.
- Damage caused by operations that are not in accordance with the User Manual.
- Damage caused by any misuse or accident.
- Damage caused by excessive usage that is not normal wear and tear.
- Wear and tear caused by normal usage that does not affect operation (e.g. normal shaver head and battery degradation).

Get professional assistance from Laifen

If you have any further inquiries regarding our warranty policy or product usage, please feel free to contact us via email at csteam@laifentech.com. We greatly appreciate your feedback and look forward to assisting you.

EU & UK Compliance Notices

EU Compliance Statement:

Shenzhen Shuye Technology Co., Ltd. hereby declares that the device (Laifen P3 3-Blade Electric Shaver with Linear Motor) is in compliance with the essential requirements and other relevant provisions of the Directive 2014/30/EU (EMC), Directive 2012/19/EU (WEEE), Directive 2011/65/EU (ROHS), Regulation 1907/2006 (REACH), and Directive (EU) 2023/1542 on batteries.

The full text of the EU and UK declaration of conformity is available at the following internet address: <https://www.laifentech.com/>



GB Compliance Statement:

Shenzhen Shuye Technology Co., Ltd. hereby declares that the device (Laifen P3 3-Blade Electric Shaver with Linear Motor) is in compliance with the essential requirements and other relevant provisions of the Electrical Equipment Safety Regulations.

The full text of the EU and UK declaration of conformity is available at the following internet address: <https://www.laifentech.com/>



Australian & New Zealand RCM Compliance Certification



Customs Union Certification



NOTICE FOR KOREA EMI STATEMENT



R-R-S0Y-LFESP3P

NOM Compliance Notices



For more information on product usage,
please visit Laifen official website: www.laifentech.com

Manufacturer: Shenzhen Shuye Technology Co., Ltd.
Address: Room 1301, Building T7, Qianwan 1st Road No. 399, Qianhai Kerry
Business Center, Nanshan, Shenzhen, Guangdong, China.