设计受控图稿

英

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING
KEEP AWAY FROM WATER

⚠DANGER

As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. Always unplug the appliance immediately after use.
2. Do not use while bathing.
3. Do not place or store the appliance where it can fall or be pulled into a tub or sink.
4. Do not place or drop the appliance into water or other liquid.
5. If the appliance falls into water, unplug it immediately. Do not reach into the water.

⚠WARNING

The appliance, filter, and attachments contain magnets:

1. This appliance and some official accessories contain magnetic elements that should be kept away from devices and objects that could be affected or damaged by magnetic fields. This includes pacemakers, defibrillators, cards with a magnetic stripe, and electronic storage media.

⚠WARNING

To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in the User Manual. Do not use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Contact Customer Support at csteam@laifentech.com for examination and repair.
5. Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
6. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
7. Never use while sleeping.
8. Never drop or insert any object into any opening.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Do not use an extension cord with this appliance.
11. Do not direct hot air toward eyes or other heat-sensitive areas.
12. Attachments may be hot during use. Allow them to cool before handling.
13. Do not place the appliance on any surface while it is operating.
14. While using the appliance, keep your hair away from the air inlets.
15. Do not operate with a voltage converter.
16. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
17. Children should be supervised to ensure that they do not play with the appliance.
18. When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.
19. For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

READ AND SAVE THESE INSTRUCTIONS
SERVICING OF DOUBLE-INSULATED APPLIANCES

1. In a double-insulated appliance, two systems of insulation are provided instead of grounding.
2. No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added to the appliance. Servicing a double-insulated appliance requires extreme care and knowledge of the system, and should be done only by qualified service personnel.
3. Replacement parts for a double-insulated appliance must be identical to the parts they replace.
4. A double-insulated appliance is marked with the words "DOUBLE INSULATION" or "DOUBLE INSULATED." The symbol (square within a square) may also be marked on the appliance.
5. WARNING: Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
6. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

ALCI Safety (U.S. and Canada Only)

1. This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature, and do not change the plug in any way.
2. This appliance is equipped with a protective device (ALCI-Appliance Leakage Circuit Interrupter) that may make it inoperable under some abnormal conditions (such as immersion of the appliance). If the appliance becomes inoperable, contact Customer Support at csteam@laifentech.com for examination and repair.
3. The appliance has a reset and test button built into the plug, which should be operated each time the appliance is plugged in and used.
   To test: press the test button. The reset button will pop out, indicating that the appliance is safe to use.
   To reset: unplug the appliance and press the reset button. Plug in again to use your appliance.
4. Note-If the ALCI trips while in use, the appliance should be unplugged. Press the reset button and reinsert the plug into the outlet. If the ALCI immediately trips for a second time, unplug the appliance and contact Customer Support at csteam@laifentech.com.

Appliance Maintenance

1. Regularly remove deposits from the air inlet using a dry towel, cotton swab, or toothbrush. When cleaning the air inlet, ensure that the power is turned off and the power cord is unplugged.
2. Avoid pressing or rubbing the air inlet and outlet with your fingernails or sharp objects to prevent damage to the appliance.
3. Do not use alcohol, nail polish remover, or detergents to clean this appliance, as they may cause malfunctions, cracks, or fading.
4. Do not attempt to repair, disassemble, or modify the appliance yourself. If a repair is required, consult the User Manual or contact Customer Support at csteam@laifentech.com.
5. If the cord of the appliance is twisted, untwist it before use.
6. If any part of the appliance shows signs of malfunctioning or damage, immediately discontinue use and consult the User Manual or contact Customer Support at csteam@laifentech.com.

Disposal and Recycling Information

Correct Disposal of This Product (Waste Electrical & Electronic Equipment) (Applicable in Countries with Separate Collection Systems)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

德

WICHTIGE SICHERHEITSHINWEISE
LESEN SIE VOR DEM GEBRAUCH ALLE ANWEISUNGEN VON WASSER FERNHALTEN

意

IMPORTANTI ISTRUZIONI DI SICUREZZA
LEGGERE TUTTE LE ISTRUZIONI PRIMA DELL'UTILIZZO. TENERE LONTANO DALL'ACQUA.

法

INSTRUCTIONS DE SÉCURITÉ IMPORTANTES
LISEZ ATTENTIVEMENT TOUTES LES INSTRUCTIONS AVANT UTILISATION. ÉVITEZ TOUT CONTACT AVEC L'EAU.

西语

INSTRUCCIONES IMPORTANTES DE SEGURIDAD
LEA TODAS LAS INSTRUCCIONES ANTES DEL USO. MANTENER ALEJADO DEL AGUA.

俄

ИНСТРУКЦИИ ПО БЕЗОПАСНОСТИ
ПРОЧИТАЙТЕ ВСЕ ИНСТРУКЦИИ ПЕРЕД ИСПОЛЬЗОВАНИЕМ БЕРЕГИТЕ ОТ ВОДЫ

捷克

DŮLEŽITÉ BEZPEČNOSTNÍ POKYNY
PŘED POUŽITÍM SI PŘEČTĚTE VŠECHNY POKYNY UCHOVÁVEJTE V SUCHU

荷兰

BELANGRIJKE VEILIGHEIDSINSTRUCTIES
LEES ALLE INSTRUCTIES VOOR GEBRUIK UIT DE BUURT VAN WATER HOUDEN

波兰

WAŻNE INSTRUKCJE DOTYCZĄCE BEZPIECZEŃSTWA
PRZED UŻYCIEM PRZECZYTAĆ WSZYSTKIE INSTRUKCJE TRZYMAĆ Z DALA OD WODY

希腊

ΣΗΜΑΝΤΙΚΕΣ ΟΔΗΓΙΕΣ ΑΣΦΑΛΕΙΑΣ
ΔΙΑΒΑΣΤΕ ΟΛΕΣ ΤΙΣ ΟΔΗΓΙΕΣ ΠΡΙΝ ΑΠΟ ΤΗ ΧΡΗΣΗ ΦΥΛΑΞΤΕ ΜΑΚΡΙΑ ΑΠΟ ΤΟ ΝΕΡΟ

土耳其

ÖNEMLİ GÜVENLİK TALİMATLARI
KULLANMADAN ÖNCE TÜM TALİMATLARI OKUYUN SUDAN UZAK TUTUN

图纸名称	Neo Special-通用11国语言Warning内容	品名	吹风机	设计	徐春梅	制图日期	25.12.5	版次	第A0版
材质及工艺	材质：80g 书纸，工艺：骑马钉	尺寸	133mm*133mm	备注				料号	

修订记录（日期）